



Hornady®

LOCK-N-LOAD® BULLET FEEDER TUBES

- Works with Hornady® feeder dies on progressive presses
- Holds approximately 28 to 34 bullets (depending on bullet length)
- Bullet Feeder Dies are sold separately (Item No. 095332)
- Not for use with lead bullets



Hornady Manufacturing Co.
P.O. Box 1848
Grand Island, NE 68802
hornady.com

LOCK-N-LOAD®
BULLETTUBE 40SW/10MM
Item No. 095351



0 90255 95351 0

INSTRUCTIONS FOR BULLET FEEDER TUBE

Hornady bullet feeder tubes have been designed to work only with Hornady pistol bullet feeder dies. Match the correct tube with the die for the caliber you are reloading. Ensuring that there is a cotter pin in the tube, fill the tube with bullets pointed away from the pin. Once full, insert the pin end of the tube into the adjustment screw at the top of the bullet feeder die. Pull the pin to release the bullets, and push down on the tube to seat it completely into the die.