



TREKLITE® COMBINATION LOCK BOX



Item No.: 95262

Ext. Dim.: 11.8" x 8.2" x 2.6"

Int. Dim.: 10.4" x 7.5" x 1.8"

Weight: 2.1 lbs.



Using this Travel Sentry® Approved lock allows your luggage to be opened, inspected and relocked by security authorities without damage.



WARNING: Do not store anything inside the lock box that may damage the firearm or contact the trigger.

HOW TO RESET YOUR NEW TREKLITE® COMBINATION LOCK BOX


To open your new lockbox for the first time:

The lock box ships with the default code 0-0-0-0. Align each digit along the center of the lock body and then rotate the knob to unlock.

NOTE: The default code must be changed to ensure the security of the lock box.

To change the code:

1. Move all 4 digits to 0-0-0-0 (or previously programmed code).
2. Make sure all digits are aligned then rotate the handle to the unlocked position.
3. Once opened, locate the lock body and program lever by gently pulling the foam back from the inside of the lid. Move the program lever from A to B on the lock housing.
4. Enter your new combination being very careful each new number is centered and aligned.
5. With the new code entered, move the program lever back from B to A.



Before shutting the lock box, test the new code multiple times to verify the new combination has been correctly set.

NOTE: The new code must be stored in a safe location, but is required to reprogram the code in the future.

***IMPORTANT:** Check TSA regulations and airline policies before traveling with any portable safe. Check dimensions of your firearm against safe's internal dimensions to ensure fit. Do not store loaded firearms in any safe or lock box. Follow local laws for firearm storage.



P.O. Box 1848, Grand Island, Nebraska 68802-1848

Hornady.com/contact